

## VIBRANT WOVEN VINYL FLOOR – INSTALLATION INSTRUCTIONS

---

Floor must be dry, levelled & crack free

- Apply self leveling compound, 24 hours prior to installation. This compound is then grinded and vacuum cleaned. Take heed, depending on the construction of the floor, of the allowed residual humidity and possible rising moisture.
- Roll the floor covering out, overlapping for about 5 cm and leave 24 hours to acclimatize.
- Fold the back over half of their length (or width) draw a mark as start for the PVC glue application. Lay the Vibrant Woven Vinyl Flooring on the wet glue and use the heavy roller to remove all air bubbles.
- Use the cold welding liquid to weld the seams, prior to that put the scotch tape on the woven vinyl floor, cut the tape using the seam. Then fit the seam by cold welding liquid.
- After few minutes, check the result.

NOTE: The flooring must be installed by professional installer.