

VIBRANT SPORTS VINYL FLOORING - CARE AND MAINTENANCE

You can protect your Vibrant Sports Floor by following these easy guidelines.

1. Clean the surface regularly using a soft broom, mop or vacuum cleaner to remove dirt, debris, and spills to avoid scratches and abrasions.
2. Use a cleaner that is specifically designed for vinyl flooring, and avoid using abrasive or harsh chemicals that can damage the surface.
3. Place mats or rugs at entry points to prevent dirt and grit from being tracked onto the floor, and to prevent slip and fall accidents.

DO

- Frequent cleaning
- Selecting suitable cleaning products
- Dealing with spills quickly
- Limit sunlight exposure
- Correct installation

DON'T

- No harsh chemicals or abrasives
- Avoid over-wetting
- Beware of sharp objects
- Avoid steam cleaning
- No oil-based cleaners