

VIBRANT LVT DRY BACK – INSTALLATION INSTRUCTIONS

Floor must be dry, levelled & crack free.

- **Preparation:**
 - Acclimate the Planks/Tiles: Allow the Vibrant LVT to acclimate in the room where it will be installed for at least 48 hours.
 - Prepare the Subfloor: Ensure the subfloor is clean, dry, level, and free of debris. Repair any imperfections.
- **Plan the Layout:**
 - Measure the room and plan the layout to minimize waste and avoid narrow pieces along the walls.
 - Use a chalk line to mark guidelines on the floor to help with alignment.
- **Apply Adhesive:**
 - Using the recommended trowel, apply the adhesive to the subfloor following the manufacturer's instructions. Start in one corner and work your way across the room.
 - Make sure to spread the adhesive evenly, covering only the area you can tile in about 30 minutes.
- **Install the Tiles/Planks:**
 - Begin laying the tiles along your chalk lines. Press each tile firmly into the adhesive.
 - Use spacers if needed to maintain consistent gaps between tiles.
 - Continue installing planks/tiles, ensuring they fit snugly together.
- **Trim Planks/Tiles as Needed:**
 - For edges and corners, measure and cut tiles to fit using a utility knife or tile cutter.
- **Roll the Floor:**
 - After all planks/tiles are installed, use a roller to ensure proper adhesion. Roll over the entire area, applying even pressure.

- **Clean Up:**
 - Wipe off any excess adhesive that may have oozed out between the tiles before it dries.
 - Allow the adhesive to cure according to the manufacturer's recommendations before walking on the floor.
- **Finishing Touches:**
 - Once cured, remove spacers and install any baseboards or transition strips to complete the look.

NOTE: The flooring must be installed by professional installer.